




AB Courtyard Collection® Reference Guide



allanblock.com

*Everything you need to know
to make installation simple.*



*Check out all the materials and information that are
available to answer your questions.*

Installation
Guide



Weekend
Project Ideas



AB Courtyard
Estimating App



Visit
allanblock.com




Reference Guide for Building with AB Courtyard

AB York Block




Straight Walls




Alternate each block.

Standard Curves



Keep all long sides together.

Modify block by cutting in 1/2.





Two AB Yorks equal one AB Dublin block.

AB Dublin Block



Straight Walls





Modify blocks by cutting in 1/2 or 3/4 length.

AB Corner Block




Corners



Modify AB Dublin block to make corner.

Posts/Pillars



Place the blocks long side out to make posts/pillars.


AB Wall Cap




Straight Walls



Standard Curves




Keep all long sides together.




Use a cut AB Dublin on the even courses to transition from a radius to ensure proper alignment.


AB Post Cap





Two AB Post Caps per post/pillar



Ensure the AB York is angled correctly to start the desired curve.




Cut AB Dublin block




allanblock.com

Visit allanblock.com.


Combining Posts and Panels




Build Corners



Finish with Step Downs (2 options shown)




Create Larger Flowing Curves



Blending the cut AB Dublin and AB York blocks allows any custom curves to be created.

- Step 1:** While building the first two courses at the same time, use a dead blow hammer to adjust transition and gaps between units to achieve desired curve. It may be necessary to slightly increase gaps to obtain desired curve.
- Step 2:** When units appear not to fit together, remove an AB York and replace with a half AB Dublin, oriented the correct direction, to overcome the tight or loose condition to obtain the desired curve.
- Step 3:** When using the Options A, B, C or D you may find that patterns do not always repeat. Use any combination of these patterns to overcome tight or loose fit conditions.

Standard Curves



Find more information or watch a video here.

Product Information



Details

Modifying Block



Details



How-to Video

Combining Posts and Panels



Details



How-to Video

Build Corners



Details



How-to Video

Finish with Step Downs (2 options shown)



Details



How-to Video
Step Down Ends



How-to Video
Vertical End

Capping a Patio Wall



Details



How-to Video

Create Larger Flowing Curves



Details



How-to Video

Capping a Curve



Details



How-to Video

Standard Curves



Details



How-to Video

Serpentine Curves



Details



How-to Video

Additional Tips - Build a Post



Details



How-to Video

Start a Patio Wall Curve



Details



How-to Video

Additional Tips - Adding Lighting



Details



How-to Video
Post Lighting



How-to Video
Panel Lighting

