

Cleaning Tips

© Amcon Concrete Products™ • February 2020 • Version 1.1

When cleaning all types of Decorative Concrete Masonry Units:

- Always specify a sample wall to be erected and approved prior to construction. This is for your reference. This panel should not be destroyed until the project is complete and accepted by all parties.
- Always pre-wet the wall prior to applying any cleaning solution. It is impossible to over wet the wall.
- Never use job mixed muriatic acid.
- On a sample panel, clean starting with a weak solution of common laundry detergent, progressing to stronger products if necessary. Apply solution in wide, course, fan spray at 100psi or less. (This is especially important with burnished units because with higher pressure the cleaning agents could become trapped behind the highlight sealer and could change or damage the color and face of the units and mortar.)
- Always rinse the cleaned area immediately to remove detergents.
- Never apply cleaning solution to dry wall.
- Never let cleaning solution dry on wall.
- Never allow high-pressure application or rinsing of cleaning solution. It can **DRASTICALLY** affect the final appearance of the wall.

Contact Amcon Concrete Products, LLC at 651-688-9116 or visit our website at www.amconconcreteproducts.com for cleaning guidelines for all types of decorative CMU's.